#1033694490

Master ID: 88063725

TECHNICAL
NOTE

8

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
PORTLAND SERVICE CENTER
P. O. Box 3861
Portland, Oregon 97208

1525.4
1400-451
P-67-165

QL
84.2
L35
no.8

TECHNICAL NOTES

MAY 7 1968

TROUGH FLOAT VALVES

The present practice to ensure proper working float valves is to replace the complete unit. The parts which become worn most of the time are the rubber washer or the leather seal. (Picture 1 & 2)

Picture 1

A float valve as ordered thru our catalogs

Picture 2

Normal disassembly of the valve

By examination it was found that the rubber washer and leather seal can be removed easily. These items can be purchased through local hardware stores and saves the purchasing of a new float valve unit. These repair parts can be carried for emergencies also. (Picture 3 & 4)

Picture 3

The washer shown removed

Picture 4

The washer and leather seal shown removed